Transitions & Collars

Fire Damper Models: MD19, MD39, MA19, MA39 Combination Fire/Smoke Damper Models: FR, FS, FT, FA, TA, FS(G), FS(C) Smoke Damper Models: SR, S, SA

Notes


- 1. A factory provided sleeve is required for the damper to utilize transitions.
- 2. Transitions can be provided for vertical or horizontal orientations.
- 3. Transitions can be provided for one or both ends of the damper (one end only for FS(G) and FS(C)).
- 4. The collar size will be approximately 0.25" smaller than the nominal duct size.


STANDARD MATERIALS AND CONSTRUCTION

TRANSITION CAP: 22-GA galvanized steel attached to damper sleeve and caulked.


DUCT CONNECTION COLLAR: 24-GA galvanized steel crimped to transition cap and caulked.

*For round duct sizes up to 36" and for oval duct sizes up to 71"W x 30"H, ABI's 24-GA duct connection collar (crimped to the damper transition) constitutes a UL approved duct-to-sleeve "Breakaway" connection, thus allowing a rigid connection collar and the round or oval ductwork.





B-PAN: 24-GA galvanized steel attached to damper sleeve and caulked at each side.



TRANSITION CAP: 22-GA galvanized steel attached to damper sleeve and caulked.

DUCT CONNECTION COLLAR: 24-GA galvanized steel crimped to transition cap and caulked.

*Requires breakaway duct to collar connection.

| April 2007 | | |
|------------|----------|------|
| Reprinted | February | 2013 |

Transitions & Collars

SD-TRFS-07.04

Fire Damper Models: MD19, MD39, MA19, MA39
Combination Fire/Smoke Damper Models: FR, FS, FT, FA, TA, FS(G), FS(C)
Smoke Damper Models: SR, S, SA

This page intentionally left blank.

