May 2018 SI-CDLG-FAPN-18.05

Installation in Fire Resistant Duct Assembly For all MCDLG Fire and Combination Fire-Smoke Dampers

Vertical Mount

APPLICATION

These instructions are for installing vertically mounted fire and combination fire smoke dampers in a fire resistant ventilation duct (UL Ventilation duct Assembly HNLN.V-5).

NOTES

- 1. The damper sleeve must slip inside the fire resistant duct spool. Damper sleeve assembly will be 1/4" (6), 1/2" (13) maximum, smaller than duct spool size.
- 2. Damper is to be supplied with factory mounted sleeve. Sleeve gauge will be minimum of 16 GA. (1.5) for dampers up to 36" wide x 24" high (914mm x 610mm) and 14 GA. (2) for dampers exceeding 36" wide x 24" high (914mm x 610mm).
- 3. Mounting angles need to be the following sizes:

• 1½" x 1½" x ¼" up to 24"

(38mm x 38mm x 6mm, up to 610mm)

• 2" x 2" x 1/4" over 24" up to 32"

(51mm x 51mm x 6mm over 610mm, up to 813mm)

• 2½" x 2½" x ¼" over 32" up to 40"

(64mm x 64mm x 6mm over 813mm, up to 1016mm)

• 3" x 3" x 1/4" above 40"

(76mm x 76mm x 6mm above 1016mm)

- 4. Mounting angle fasteners:
 - #10 (4) bolts or screws
 - 3/16" (4) steel rivets
 - 1/2" (13) long welds
- 5. Mounting Angle Fasteners Spacing:
 - · Mounting angles to dampers, space fasteners on 6" (152mm) on center.
 - Mounting angle to spool flange, space fasteners on 12" (305mm) on center.
 - Minimum 2 fasteners per side.
- 6. Hanger rods:

3/8" (10) threaded rod anchored to the floor above and attached to the mounting angles through hole in the angles and secured with hex nut and washer (items 5 & 6). Anchor to masonry per assembly No. V-5.

7. Duct to Damper Sleeve Connection:

See the fire damper or the combination fire-smoke installation instructions for breakaway, flanged, or non-breakaway connections.

SUPPLEMENTAL INSTALLATION **INSTRUCTIONS / SUBMITTAL DATA**

One-Side Retaining Angles (SI-CDLG-FSOS)

Out-of-Wall/Floor (SI-CDLG-OOWFD)

Alternate Out-of-Wall/Floor C-Style (II-CDLG-OOWCFD)

Sleeve Extension (SI-CDLG-SLVEXT)

Transfer Openings (SI-GFTD)

Installation of Flanged Duct Connections for UL Dampers (SI-CDLG-ULFDC)

Security Bars (SD-SB)

Transitions - C-Style, Round, Oval, or Square (SI-CDLG-TRFD)

Transitions - B-Style Round, Oval or Square (SI-BPAN)

Sleeves & Sideplates (SI-CLDG-SLVS)

Position Indication Switch Package (SI-CDLG-SWITCH)


PK1202 Switch Package (SI-CDLG-PK1202)

Retaining Angles (SI-TLRA)

Corrugated Decking (SI-DECKING)



Please refer to the UL or ULC Classification Marking on the Product.











Installation in Fire Resistant Duct Assembly For all MCDLG Fire and Combination Fire-Smoke Dampers

Vertical Mount

Item	Description
1	Fire Resistant Ventilation Duct (UL HNLN Assembly No. V-5)
2	Fire Damper or Combination Fire-Smoke Damper
3	Hanger rods in accordance with assembly No. V-5
4	Mounting angles (see Note 3, Page 1)
5	3/8" (10) hex nuts
6	%" (10) flat washer
7	Mounting angle fasteners (see Note 4, Page 1)

